
GETTING STARTED

This guide shows how to use the ctrlX Device Portal to add licenses to your ctrlX AUTOMATION devices and manage them.

Go to the <u>ctrlX Device Portal</u> and log in.

If you do not have access yet, please register. You can find detailed instructions in the ctrlX AUTOMATION Community.



2	After login you will be redirected to the overview of
	the devices.

exroth						seet A.	
			ES A LICENSES	-	PREMIUM ACCOUNT		
Devic	es						
All American	a second dataset	manachine still willing	2010 (10) 78	*		REGISTER NEW DEVICE	
-	Draite Name	Frequencies			Total	Barriel Services	
Ð	2010/07/05/2				1198	2(inamole	
8	LINE STATE				1046	Instalaerians.	
10	LIMA-MININ				000	containen.	
0	laterateria				50M	Canadaretia.	
	131-MORE FRAME				One	typineminist	
10	GR08/8845				core	424144103975	
12	DAVAGENE				com.	America .	
13	2245-402522AM				51.94	Alarian Provide	

USING THE ctrlX Device Portal

The Bosch Rexroth Licensing Center can be used to track and manage your license assets and map entitlements to devices. After you have received the confirmation e-mail, that your ctrlX AUTOMATION license has been generated and added to your customer account, you can access and manage your licenses here.

TERMS

Device

A device can be the ctrlX CORE, your PC or other devices that are using the licensing and software deployment provided by ctrlX AUTOMATION.

App license

An app license is needed to be able to use an app. Each license has an individual material number that can be ordered. There are add-on licenses that can only be activated if the base license is installed.

License file

The license file can be downloaded via the ctrlX Device Portal and is uploaded to your device either manually or automatically if the device is online. To start an app your device must have the license file on board.

App file

You can decide if the ctrlX Device Portal should create a license file with or without apps. If you just want the app file, download the apps in the appropriate version in a package so you can install them on your device.

More information: <u>ctrlX AUTOMATION website</u> <u>ctrlX AUTOMATION Community - How to</u> <u>ctrlX Store</u> <u>Online documentation</u>



VIEW DEVICES

Select **devices** in the top to view a list of all your available devices with corresponding information.

Your ctrlX CORE and SD dongle are added automatically after shipping.

Click on the device name to access more details and to start adding apps and licenses to your device.

a Smith foregang						R	ctrl
our 7 haar Australia (tota (100, hours of							
	BEVICES	-	onocau	PREMIUM ACCOUNT			
MOTION Sent because	IX CORE - Mo				🖓 esti Store		
ctriX							
DEVICES OVERVIEW LI	INTA OUTVIEW						
BURGER BURGER							
		Yester					
Rein							

VIEW APPS AND LICENSES

Select **apps & licenses** in the top menu. A list of all your licenses will be shown. Licenses can be grouped by apps or viewed in a list.

You can search by the name of the app or the license, as well as filter by order number.

The total quantity indicated how many have been ordered, while the available quantity shows how many are left. The expiration date indicates when the license expires.

Click on the name of the app to access more details.

More information: <u>ctrlX AUTOMATION website</u> <u>ctrlX AUTOMATION Community - How to</u> <u>ctrlX Store</u> <u>Online documentation</u>

Within a device, you can see which apps and licenses are already installed, including the app version and the quantity of licenses. The order number from which the license was taken is also displayed.

Next to the device name, you can edit the name via the pen symbol.

Click see more to access further information about the device such as material number or last updated date.

rexroth								R	ctr
								and the second second second	
					ALICENSES OR	IDENIS PREMIUM ACCOUNT			
		8	72614	0411453	0 /				
		ŧ.	factal sumbani Last modified	NOTI 42 DETUGATION IN CONE	Material resolution Type code:	CONTRACTOR CONTRACTOR			
			+ San Jan					Frommont	
							-		
	0				Garnet Bealer	Dole-Basilies	Gaardia	Actions	
1	> 😨	a8.000.18	stal.Memoriles						
	-	1012092.00	in Ann						
	-	trik tanky mad	The state of the second of	-			1000 1000	8	
			Ann .						

You can get more information about the app. Click on ctrlX Store to purchase more licenses.

Below the description you can see on which devices the app and the matching licenses have been added.



VIEW ORDERS

Select **orders** in the top menu to review your license orders.

You can search by order number.

Within each order you can check license name, material number and purchased quantity.

xroth					
		MANCES APPS & LICEN	NS 40	Anna Account	
Order	s				
Mikle Mil	alda di kintik 👘				
22	New	Griter Planet	Casine By	Massia Monko	Parities of Generica
· •	(antimid				
> •	******				
· •	ACCOUNTS OF		mage species (but beach more		
>)	1 (mm)				
> ©	404498.00		Date in the second second		
> 💿	1271484				
>)			Same Paramager bank com		
>)	entried		press printing a surface		
· •	10-10005		tert hat safe-gat territ of	-	
· 🕤	anniana ci				
>)	stad.				
· 🕤	- encount				
· •	aggernadi				
) (O)	animeter of				
> ©	anned .				
> ©	mernet				
· •	GIN				
· •	astronaut				

PREMIUM ACCOUNT


Select **premium account** in the top of the menu to access additional device related features.

rexroth					 ctrlX
	DEVICES	APPS & LICENSES	CHORES.		
Premium	Device Managem	ent			
	Team-Account			ISO TO MY PRESENCE ACCOUNT	

If you do not have a subscription you get the information how to purchase one.

rexroth	A ctrD
BRVCES	APPE & LICOMES ORDERS PERMIN RECOURT
Pron	nium device management
110	
Receive the effective of provide	Bing you derive mempreset to the card low! AN CODE dealers handling againments in gegending your with Generic Party in Pression.
1000000	
BASIC	PREMIUM
And Access to 1995 Dama	V Apple Accellence (1979) Tarres
/ App - Control to FC	✓ App Annual to the serve
America - Diversitat WPS	/ LINES - THE REAL PROPERTY IN
	V Apr - Autorial (consult) (autor)
	C App - Colorer app adval
	Service configuration - Contrast configuration
	Cervice configuration (
	Automatic developed to churche developed
	- Renate access - D and Philippin
	Common mentiles i taciture mentiles
	 Approximation Approximation (contractions)

More information: <u>ctrlX AUTOMATION website</u> <u>ctrlX AUTOMATION Community - How to</u> <u>ctrlX Store</u> <u>Online documentation</u>





LICENSE YOUR DEVICE / ASSIGN APPS

Go to the **device** you want to assign the licenses to and click on **assign apps & licenses**.

	rexroth						B	c
	a l'anna i stanoresta							
State Andream TELESCIONS Manual canadas TELESCIONS Canadas TELESCIONS Telescions TELESCIONS Canadas Canadas TELESCIONS Telescions Canadas Canadas Telescions Telescions Canadas Canadas Telescions Telescions Image: Telescions Telescions Telescions Telescions				4 LICENSES ON	DERS PREMIUM ACCOUNT			
Name Dataset Name <thdataset name<="" th=""> Dataset Name</thdataset>		72	26140411453	0 /				
- San San - San		ALMON TANK	mailful 200102-09735-03-00	If Type under	COMPANY AND A ADDRESS AND ADDR			
Image: Control of the contro		100						
Image: Control State Answer Control State Control State Answer > mill State State Control State Answer > mill State State Control State Answer > mill State State Control State Answer								
> anti-Off. IntelChamble > enti-Off. IntelChamble Enti-Off. IntelChamble has '								
 militäli äineite militäli äineite militäli äineiteen 						Annes	N MPS & UCENCES	
en un contrans transmission transmission transmission and the second sec	0.0	Read of the local data		Carnet Broker	Dide Ballion			
			m.tee	Carner Broke	Do Balla			
	> 😨	100.000. 53e055.2ee	m.lee	Carner Basin	Dir Belle			
	> • • •	onit 2002, She 242 Mar anit 2002, She Ara		Career Beeler	Der Refer		Arites Ê	

3 Once you have selected an app, you see which licenses belong to it:

Select the quantity of licenses via the drop down and **click on next**.

	s to "7261404114530		
		(a) (13/80.000	
Bairs	Explorem	Autom Garry	Antigent Anticentry
The second second second			
3			
🖬 3 🛒 mik CORE Bred Cit Marin Age			
🚊 🤉 📑 anti CORE: Status Ann			
🗈 > 票 aak cole . At they			
🖬 🐱 🜉 uni cont i industri na			
1 - 1 month committee market			
	Perman	1.00	1.0

2 Select the application by checking the box.

Apps with a grey background indicate that a license for the app is already assigned.

The quantity can be updated even after a license was assigned.

		7261404114530			
	Statest of Sales		() continues		
<i>.</i>	Barry	Equiption	Available Generally	Antipert	Add Generally
4498					
- 3 🖶					
12 > 🗮	INK CORE - BROCHT Marine App				
11 > 🗮	orel CORE - Station App				
8 > 🖶	HAR CONT - HILL New				
-	UNICONE - Inde-PET-Age				
Institute	an ancard and its				
1 223	milk CORE I hade-fied Liverage	Patranet			

Select the version of the app you would like to use and confirm via **next**.

croth				A
	n apps & licenses to "726	1404114530"		
	1 SECT MASSICENSES	Sartunasa — (s)taqaada		
-	Anne	famous r	Testin	
	m9-0240-14-04-103 Apr			
-	off (010), Nute-Part James			
randin.				

More information: <u>ctrlX AUTOMATION website</u> <u>ctrlX AUTOMATION Community - How to</u> <u>ctrlX Store</u> <u>Online documentation</u>



LICENSE YOUR DEVICE / ASSIGN APPS


5 The summary page gives an overview which apps and licenses you would like to assign to the selected device.

Proceed with next.

Assign apps	& licenses to "7261404114530"	3 CH 199	
Summary	Appt & Literate In the Assigned		water
-12911010110000	with CORE - Male RET Age	(anomi-	10-200
	en con coli - Man-Mat (annes		
COMPR.			

6 The assignment was successful when the pop-up appears.

To download the app and license file proceed with the download button.




DOWNLOAD FILE

Go to the **device** that you want to assign the licenses and then click the button **download**.

Choose whether you want to download only the licenses, only the applications, or a file that contains both applications and licenses. 2 The file is now ready to be uploaded to your device, e.g. via the device interface.

Click on download to proceed.



More information: <u>ctrlX AUTOMATION website</u> <u>ctrlX AUTOMATION Community - How to</u> <u>ctrlX Store</u> <u>Online documentation</u>



COPYRIGHT

The data in this document may not be altered or amended without special notification from Bosch Rexroth AG. Bosch Rexroth AG undertakes no further obligation in relation to this document. The software presented herein is provided on the basis of a general license agreement or a single license. Using and copying is only allowed in concurrence with the specifications stipulated in the contract. Under no circumstances may any part of this document be copied, reproduced, transmitted, stored in a retrieval system or translated into another language without the express written permission of Bosch Rexroth AG.

© Copyright 2023, Bosch Rexroth AG, Lohr am Main

The names and designations used in this document are trademarks or brands belonging to the respective owners.

More information: ctrlX AUTOMATION website ctrlX AUTOMATION Community - How to ctrlX Store Online documentation

© Bosch Rexroth AG 2023 Subject to change!

